



# SPECPRO™ SET-UP AND MAINTENANCE



Battery Compartment  
Battery Cover  
Battery Clip

**Step 1:** Power SpecPro™ with either its AC adapter or a 9 volt battery. **WARNING: USE ONLY THE AC ADAPTER SUPPLIED BY KRELL.**



Platen Platen Liner

Bearing Hole

Locking Handle

Base Post

Drive Bearing

Base Liner

**Step 2:** Place platen on base plate making sure it sits upon the drive bearing


## FOR SAFE OPERATION

- Use only Krell AC adapter
- Keep hands away from all moving parts
- Do not use excessive water during operation
- Do not operate with loose clothing, ties, jewelry, etc.

**TO STOP POLISHER,  
DEPRESS THE POWER  
SWITCH**

## MAINTENANCE

- Always disconnect AC adapter during maintenance
- Replace platen and base liners approximately every 200 hours of operation
- Keep all surfaces dry and clean between polishing sessions
- Clean connector positions with supplied brush



Pressure Pins\*


Locking Handle

Washer

**Step 3:** Engage workholder with base post. Make sure the washer sits between locking handle and workholder. Align workholder square with polisher and lock.

\*New generation SpecPros use pairs of pins to maintain pressure.

Upper Pin



Pressure Bar

Connector Positions

**Step 4:** Lift connector positions upward using the pressure bar. Slide upper pin beneath bar to hold.

Dial Timer



**Power and  
Emergency  
Stop Switch**